

Tools and Material Required

Suitable valves included
 Pipe dope
 Tape measure
 Allen Wrench
 Screwdriver
 Electric Drill
 Drill Bit - to suit screw

| Key | Hardware Supplied | Qty |
|-----|-----------------------|-----|
| A | Air Vent - 1 / 4 inch | 1 |
| B | Screw - #8 x 1.5" | 4 |
| C | Valve Set (D) (NPT) | 1 |

Assembly Instructions

Sufficient quality pipe dope must be applied to valve- tail threads prior to their installation.

Install the valves using the correct (1 / 2 inch) size Allen Wrench

Install Air Vent (A).

Connect the radiator to heating circuit with air vent on the return end.

Accurately mark the holes to mount the pedestal bases , to dimensions shown on the SPECIFICATION DATA sheet.

Drill holes to suit screws (B).

Fix the radiator to the floor with screws (B).

